

CHAMPION AGILITY

JUMP STANDARD ASSEMBLY INSTRUCTIONS

Check the contained parts with the list below

Part	Description	Qty
SP-0001	Jump Standard Pole	2
SL-0001	12" Leg	2
SL-0002	18" Leg	2
CD-1250-2520	1-1/4" Cross Dowel	2
HB-1250-2520	1" Hex Bolt	4
JC-0001	Jump Cup	10
MS-1250-0632	1-1/2" x 6-32 Screw	10
WN-0632	6-32 Wing Nut	10
HN-2520	1/4" Hex Nut	2
SC-0001	1" Safety Cap	2

If parts are missing, logon to: www.championagility.com and replacement parts will be shipped out to you.

- 1 Assemble the Jump Standard Legs with the 1" Hex Bolt and one of the Nuts.
- 2 Attach the Jump Standard Pole to the Leg Assembly from ① using a cross dowel and a 1" Hex Bolt.
- 3 Attach the Jump Cups at the Heights that you want using a 1-1/2" Screw and a Wing Nut. There are 9 possible jump Heights ascending from the bottom: 6", 8", 10", 12", 16", 20", 24", 22" and 26"
- 4 Push the Safety Cap onto the top end of the Jump Standard Pole.

